

## CSCE 462/862

### Communication Networks

---

#### The Physical Layer

Steve Goddard  
*goddard@cse.unl.edu*

1

#### Transmission Media

---

- ◆ Magnetic Media
- ◆ Twisted Pair
- ◆ Baseband Coaxial Cable
- ◆ Broadband Coaxial Cable
- ◆ Fiber Optics
- ◆ Wireless

2

#### Transmission Media

---

- ◆ Magnetic Media
  - » Cheap: \$.10/Gigabyte
  - » High bandwidth
  - » High Latency
- ◆ Twisted Pair
  - » Unshielded Twisted Pair (UTP)
  - » Cat 3 or Cat 5
  - » Phone lines implement a cut-off filter near 3000Hz
    - ◆ Limit of 38,400 baud
    - ◆ Can get > 38.4k bps by encoding multiple bits in a signal

3

#### Transmission Media

---

- ◆ Baseband Coaxial Cable (Coax)
  - » 50 ohm Cable used for digital transmission
  - » Better shielding than twisted pair
  - » Bandwidth depends on cable length
    - ◆ 1 km cable can transfer 1 or 2 Gbps
- ◆ Broadband Coaxial Cable (> 4000Hz)
  - » 75 ohm Cable used for analog transmission
  - » Broadband networks use cable TV technology
    - ◆ up to 100km and 300-400 MHz
    - ◆ Bandwidth depends on number of bits encoded within each Hz.
  - » Divided into multiple channels
    - ◆ Broadcast both TV and data on one cable

4

#### Transmission Media

##### Broadband Coax

---

- ◆ Amplifiers amplify the signal in one direction
  - » Dual cable systems (Fig. 2.4a)
    - ◆ transmit on cable 1
    - ◆ receive on cable 2
  - » Single cable systems (Fig. 2.4b)
    - ◆ Split the frequency for transmitting and receiving
      - ◆ Subsplit
        - receive on 4-30 MHz frequencies
        - transmit on 40-300 MHz frequencies
      - ◆ Midsplit
        - receive on 5-116 MHz frequencies
        - transmit on 168-300 MHz frequencies
- ◆ Inferior to Baseband, but ubiquitous

5

#### Fiber Optics

---

- ◆ Bandwidth
  - » 1 Gbps today
  - » 100 Gbps in lab
  - » 1000 Gbps = 1Tbps soon
- ◆ Components of optical transmission
  - » Transmission Media
  - » Light source
  - » Detector

6

## Fiber Optics Transmission Media

- ◆ Ultra-thin fiber of glass
  - » See Fig. 2-7
  - » Multi-mode fiber
    - ◆ 50 micron diameter: width of a human hair
    - ◆ light sent at an angle, Fig. 2.5(b)
    - ◆ multiple light sources create multiple signals on one fiber
  - » Single-mode fiber
    - ◆ 8-10 micron diameter
    - ◆ light travels a straight line
    - ◆ > 1 Gbps for 30+ km

7

## Fiber Optics Light Source

- ◆ Light source
  - » LED (Light Emitting Diode)
  - » Semiconductor laser
  - » Fig 2.8

8

## Fiber Optics Detector

- ◆ Detector
  - » Photodiode
  - » Generates a pulse when light hits it
    - ◆ 1 if light is on
    - ◆ 0 if light is off
  - » 1 ns response time
    - ◆ limits bandwidth

9

## Fiber Optics Network

- ◆ Ring Topology
  - » Passive interface
    - ◆ Failure of interface diode/LED does not affect rest of network
    - ◆ Attenuation of the signal can be a problem
  - » Active interface
    - ◆ Fig. 2-9
    - ◆ Failure of interface brings down the network
    - ◆ Signal is regenerated to full strength at each interface
- ◆ Passive Star Topology
  - » Fig. 2-10.
  - » connectivity is limited by sensitivity of diodes

10

## Fiber vs. Wire

- |  |   |
|--|---|
| <ul style="list-style-type: none"><li>◆ Fiber<ul style="list-style-type: none"><li>» High bandwidth</li><li>» Low attenuation</li><li>» Not affect by<ul style="list-style-type: none"><li>◆ power surge/failure</li><li>◆ EMF</li><li>◆ Harsh environment</li></ul></li><li>» Thin and lightweight<ul style="list-style-type: none"><li>◆ 1km cable of 2 fibers weighs 100 kg</li></ul></li><li>» Hard to tap: security</li></ul></li></ul> | <ul style="list-style-type: none"><li>◆ Wire<ul style="list-style-type: none"><li>» More familiar material</li><li>» Bi-directional</li><li>» Cheap interfaces</li><li>» Thick and heavy<ul style="list-style-type: none"><li>◆ 1km cable of 1000 twisted pair weighs 8000 kg</li></ul></li></ul></li></ul> |
|--|---|

11

## Wireless Transmission

- ◆ When electrons move, they create electromagnetic waves
  - » # of oscillations/sec = frequency (f)
  - » Distance from maxima to maxima = wavelength ( $\lambda$ )
  - » Attach antenna to circuit to broadcast/receive waves
- ◆ Transmit signals by modulating
  - » Amplitude,
  - » Frequency, or
  - » Phase

12

## Wireless Transmission Electromagnetic Spectrum

- ◆ Fig. 2-11 shows frequency bands used for communication
  - » Notice where Fiber Optics lies
- ◆ Bit encoding increases transmission rate
  - » Encode 3 bpHz at low  $f$
  - » Encode 40 bpHz at high  $f$ 
    - ◆ 500 MHz cable can transmit > 2 Gbps

13

## Wireless Transmission Electromagnetic Spectrum

- ◆ Low frequency signals
  - » omni-directional
  - » penetrate objects
- ◆ High frequency signals
  - » narrow, focused signal
  - » absorbed/deflected by objects

14

## The Telephone System

- ◆ WAN
  - » Expensive to run lines for WAN
  - » Therefore, most WAN use PSTN (Public Switched Telephone Network)
- ◆ Evolution of PSTN
  - » See Fig. 2-14
    - Phones were hard-wired to each other
    - Switching center created for a city
    - Multi-level switching offices to connect cities

15

## The Telephone System (cont.)

- ◆ Today's U.S. telephone network
  - » See Fig. 2-16
    - ◆ 160 LATAs (Local Access and Transport Area)
    - ◆ usually one LEC (Local Exchange Carrier) per LATA
    - ◆ All inter-LATA traffic is handled by an IXC (InterXchange Carrier)
    - ◆ Any IXC can build a POP (Point of Presence) in a LATA and gets equal access to inter-LATA traffic

16

## The Telephone System (cont.)

- ◆ 3 main components
  - » Local Loops
    - ◆ twisted pair
    - ◆ analog signaling
  - » Trunks
    - ◆ Fiber optics or microwave
    - ◆ mostly digital
  - » Switching Offices

17

## Local Loop Computer Communications

- ◆ Modem (modulator-demodulator)
  - » Send digital data over analog lines
  - » See Fig. 2-17
- ◆ Problem with using analog communications
  - » Attenuation
    - ◆ loss of energy as signal propagates
  - » Delay distortion
    - ◆ Fourier components travel at different speeds
  - » Noise
    - ◆ unwanted energy from external sources

18

## **Local Loop Computer Communications**

- ◆ AC signal is used to handle attenuation and delay distortion
- ◆ Sine wave carrier signal used to modulate
  - » Amplitude
    - ◆ 0, 1 represented by varying voltage level
  - » Frequency
    - ◆ 2 or more tones
  - » Phase
    - ◆ wave is shifted 45, 135, 225, or 335 degrees
    - ◆ each phase shift represents 2 bits of info
- ◆ Combining modulation techniques increases bps per baud

19

## **Local Loop High Speed Communications**

- ◆ Shorter twisted pair local loop
  - » FTTC
  - » See Fig. 2-23
- ◆ Different media in the local loop
  - » Coax: cable modems
  - » FTTH
  - » Wireless ?

20

## **Trunks and Multiplexing**

- ◆ Frequency Division Multiplexing: FDM
  - » Frequency spectrum is divided into logical channels
  - » Each user has exclusive use of a frequency band
  - » See Fig. 2-24
- ◆ Wavelength Division Multiplexing: WDM
  - » FDM over fiber: Fig.2-25
  - » Completely passive
- ◆ Time Division Multiplexing: TDM
  - » Each user gets entire bandwidth is used to transmit data
  - » Round-robin access: Fig 2-28.

21